

# awave



awave

Guangzhou Oaktree Trading Co. Ltd

Tel: 020-37684200

WeChat Account: gzoaktree2013

Website: [www.awaveaudio.com](http://www.awaveaudio.com)

Address: Room 102, Building 16, No. 2, Erheng Road, Hebian Tongda Creative Park,  
Helong Street, Baiyun District, Guangzhou

## LUG11 PRO USER MANUAL

## ■ INTRODUCTION

Thank you for purchasing a AWAVE amplified sub woofer for your car sound system. This amplified sub woofer system utilizes Well without taking up the space too much in your vehicle and it can be simply and invisibly installed via the provided plug and play harness. If you decide to install the LUG11 PRO by yourself, please thoroughly read through this manual before getting started. This manual will help familiarize yourself with this amplifier and guide you through the installation process and procedures.

## ■ Features

- Sealed cast aluminum enclosure.
- Plug and Play connection system, easy to hook up.
- Easy installation and removal.
- Completely hidden installation and out of sight.
- Remote control provided for volume.

## ■ Contents

|  |       |
|--|-------|
| 1. Spare tire active subwoofer                 | 1 pc  |
| 2. Ower's Manual (Chinese)                     | 1 pc  |
| 3. Ower's Manual (English)                     | 1 pc  |
| 4. Remote control & Plug and play wire harness | 1 pc  |
| 5. High input wire & Low input wire            | 1 pc  |
| 6. Power plug                                  | 1 pc  |
| 7. Screw with nut                              | 1 pc  |
| 8. Mounting Bracket                            | 1 pc  |
| 9. Magic Tape                                  | 2 pcs |
| 10. EVA  | 2 pcs |

## I SIGNAL INPUT & POWER CONNECTION

Fig.1:





Fig.2:



## I SPECIFICATIONS

| MODEL:                        | LUG11 PRO       |
|-------------------------------|-----------------|
| RMS power                     | 500W            |
| THD                           | <0.5%           |
| Signal-to-noise ratio         | >95dB           |
| Frequency response            | 25Hz-200Hz      |
| Input sensitivity, high level | 280mV-10.8V     |
| Input sensitivity, low level  | 140mV-5.4V      |
| Low Pass Filter               | 50Hz-200Hz      |
| Bass Boost                    | 0 to +12dB      |
| Subsonic Filter               | 25Hz            |
| Fuse rating                   | 30A             |
| Subwoofer                     | 11inch, 0.15ohm |

All specifications subject to change without notice

## I WARNING

LUG11 PRO built-in amplifier and bass are special low impedance design system, the amplifier and bass can not be replaced by traditional amplifier and traditional bass, otherwise it will burn the amplifier and bass!


# POWER CONNECTION

A:Connect the ground terminal to the closest point on the chassis of the vehicle.Keep this ground wire to less than 39"(100cm) in length. Use 8 gauge(or heavier) wire (NOT SUPPLIED).

B:connect the remote terminal to the remote output of the head unit using 16 gauge (NOT SUPPLIED)(or heavier) wire(only Low Level input method).

C:Connect an empty fuse holder within 18"(45cm) of the car battery, and run 6 gauge (or heavier) cable (NOT SUPPLIED) from this fuse to the amplifier location. Then connect the fuse holder to the "BATT+"(+12v) connection on the subwoofer.

Fig.3:



A.Connect the ground/negative cable(Black wire) to any solid metal grounding point of your vehicle body.

Fig.4:



C.Run the power/positive cable(red wire)to get the power from your vehicle's battery.(connect the power cable to the positive pole of the battery)

## Troubleshooting

If you experience operation or performance problems with this product, compare your installation with the electrical wiring diagram on the previous pages. If problems persist, read the following troubleshooting tips which may help eliminate the problems.

| SYMPTOM   | POSSIBLE REMEDY   |
|---|---|
| <b>Amplifier will not power up.</b>                         | <i>Check to make sure you have a good ground connection.</i><br><i>Check that the Remote Input (Turn-On) has at least 5VDC.</i><br><i>Check that there is battery power on the (+) terminal.</i><br><i>Check that there is at least 12v.</i><br><i>Check all fuses, replace if necessary.</i><br><i>Make sure that the Protection LED is not illuminated. If it is lit, shut off the amplifier briefly, and then repower it.</i>  |
| <b>Protection LED comes on when amplifier is powered up</b> | <i>Check for short circuits on speaker leads.</i><br><i>Turn down the volume control on the head unit to prevent overdriving.</i><br><i>Remote speaker leads, and reset the amplifier. If the Protection LED still comes on, then the amplifier is faulty and needs servicing.</i>  |
| <b>No output.</b>   | <i>Check that all fuses are OK.</i><br><i>Check that unit is properly grounded.</i><br><i>Check that the Remote Input (Turn-On) has at least 5VDC.</i><br><i>Check that the RCA audio cables are plugged into the proper inputs.</i><br><i>Check all speaker wiring.</i>  |
| <b>Low output.</b>  | <i>Reset the Level Control.</i><br><i>Check the Crossover Control settings.</i>   |
| <b>High hiss in the sound.</b>                              | <i>Disconnect all RCA inputs to the power sub's control panel. If the hiss disappears, then plug in the component driving the amplifier and unplug its inputs. If the hiss disappears at this point, go on until the faulty/noisy component is found.</i><br><i>It is best to set the amplifier's input level control as low as possible. The best subjective signal-to-noise ratio is achieved in this manner. Try to set the head unit as high as possible (without distortion) and the amp input level as low as possible.</i> |
| <b>Squealing noise is present.</b>                          | <i>Check for improperly grounded RCA interconnects.</i>   |
| <b>Distorted sound.</b>                                     | <i>Check that the Input Level Control is set to match the signal level of the head unit. Always try to set the Input Level as low possible.</i><br><i>Check that all crossover frequencies are properly set.</i><br><i>Check for short circuits on the speaker leads.</i>   |
| <b>Amplifier gets very hot.</b>                             | <i>Check that the minimum speaker impedance for the amp model is correct.</i><br><i>Check that there is good air circulation around the amp. In some applications, it may be necessary to add an external cooling fan.</i>  |
| <b>Engine noise (static type)</b>                           | <i>This is usually caused by poor quality RCA cables, which can pick up radiated noise. Use only the best quality cables, and route them away from power cables.</i>  |
| <b>Engine noise (alternator whine)</b>                      | <i>Check that the RCA grounds are not shorted to the vehicle chassis.</i><br><i>Check that the head unit is properly grounded.</i>  |

## ■ INSTALLATION GUIDE

Fig.5:



Fig.6:




Fig.7:



Fig.8:



## ATTACHMENT INSTALLATION DIAGRAM

Fig.9:




Fig.10:





Fig.11:



## PRODUCT DIMENSIONS

